



House Builders Pocket Guide





Built-In Ovens

Everyday cooking has never been so easy

Ovens that feature simple controls to help you dish up weekday meals in under an hour, and with a range of cleaning functions, like Click&Clean, keeping your oven sparkling is a breeze.



Turn&Go

Family meals in just one hour

Simply turn the dial, and the oven will automatically set the temperature for over 100 recipes, turning off when everything is cooked - weekday meals couldn't be simpler.



Telescopic Shelves

Check on your food without the risk of your dish tipping

Enjoy shelves that never tip, so when you're removing food, or simply stirring before placing back in the oven, you can do so with confidence, knowing that the shelf will not tip over.



Multi-Cooking

Make family meal times a breeze

Features up to 11 pre-set cooking functions that assist you in the kitchen and make cooking a breeze, so you can enjoy more time with the family.



Tilting Grill

Better access for easier cleaning

Cleaning the grill is no longer a struggle. The Tilting Grill pulls outwards and downwards for better access, making the cleaning process a lot easier.

Oven Cleaning Technology

Save time and effort when cleaning your oven



Pyrolytic Cleaning

Pyrolytic Cleaning uses a high-temperature cycle to burn off any food residue.



Steam&Clean

Steam&Clean features a handy cleaning cycle that harnesses the power of steam.



Easy Clean Enamel

Easy to clean enamel liners prevent food from sticking inside the oven, just wipe with a damp cloth.



Click&Clean

It takes just two clicks to remove the inner glass from the door of your oven, so you can simply wipe it clean - an effortless way to keep your oven clean.



Microwaves

Fast and easy to use microwaves to save you time in the kitchen

Indesit's microwaves combine speed, versatility, and smart features to make life easier. From warming baby bottles to defrosting evenly or preparing quick meals, they simplify every task.



Push&Go

Maximum power with one push

Press the Push&Go button and your microwave will cook on full power for 30 seconds, perfect when you're rushing around to serve the dinner.



Auto Defrost

Defrost with total ease

Quickly defrost your food safely and evenly. Simply select your food category and weight and let the microwave defrost with total ease.



Double Power Wave

Even cooking without hot or cold spots

Fast and effective cooking makes life that little bit easier. The Double Power Wave system provides delicious and evenly cooked food without cold or overcooked spots.



EasyClean

Keep your microwave squeaky clean

Banish the chore of cleaning the microwave. The eco-friendly EasyClean cycle needs only a small bowl of water inside the cavity, so you can keep your appliance squeaky clean without using chemicals.



Freestanding Cookers

Indesit makes it easy to keep your cooker sparkling

When cleaning the oven is quick and simple, you can enjoy making delicious dishes for the whole family, without worrying about the mess.



Steam&Clean

Harness the power of steam to keep your oven clean

Steam&Clean eliminates fat and grease in your oven in just 35 minutes, so you can spend more time doing the things you love, and less time scrubbing the oven.



XL Cavity

Large oven capacity for all your cooking needs

There's plenty of space to prepare multiple meals that will save you time in the kitchen.



Click&Clean

Cleaning your oven door is quick and simple


It takes just two clicks to remove the inner glass from the door, so you can wipe it clean, and keep your oven sparkling like new.



Catalytic Liners

Reduces the time spent on cleaning

An oven that removes fat and grease naturally during the cooking process. Thanks to Catalytic liners you can spend less time cleaning, and more time cooking.



Hobs

Cooking your favourite family meals has never been so easy

Spend more time together and less time cooking, our easy-to-use hobs give you flexibility and are designed to make your life easier. Discover our range of induction, ceramic and gas hobs, perfect for dishing up your favourite family meals, from a tasty stir-fry to delicious dippy eggs.



Push&Go

**Set the ideal power level
at the touch of a button**

An easy solution for cooking everyday family meals. Push&Go hobs provide three automatic functions to make life easier. Boil water, keep food warm, and make coffee at just the touch of a button.



Easy to Install

**Fits every style
of kitchen**

With its slim body and friendly design, our Indesit Push&Go induction hobs easily fit with every style, every need and every kitchen.



Easy Cleaning

**Less time cleaning,
more time together**

Cook your favourite family meals without worrying about spending too much time cleaning up afterwards. Save on time and energy with an easy-to-clean hob.



Dual Zone

**Flexible cooking for
easy family meals**

Batch cooking in a large pan? Combine two separate cooking zones to create one extra-large heat surface, perfect for even the biggest of pots and pans.



Cast Iron Supports

**Wear and tear resistant
pan support**

Indesit gas hobs feature cast iron pan supports, so you know they're durable enough to stand the test of time in your kitchen while providing stability for your pots and pans.





Hoods

Keep your kitchen smelling fresh

With easy-to-use controls and removable filters, there's no better way of keeping your kitchen free from unwanted cooking odours.



LED Lighting

**Brighter, more
efficient lighting**

Our brighter LED lighting uses up to 90% less energy and lasts 10 times longer than traditional Halogen lighting. Enjoy brighter visibility when cooking and save on energy.



Dishwasher-safe Grease Filter

Effortless and easy cleaning

A hassle-free grease filter that can be popped into the dishwasher, ensuring easy cleaning and maintenance, so you can spend more time with the family.





Built-In Dishwashers

Make cleaning up after family meals a breeze

Doing the dishes is quick and easy. Our dishwashers leave your cups, crockery and cutlery sparkling with minimal effort, and with Push&Go, everyone in the family can get involved.



Push&Go

Clean and dry dishes with just one push

Enjoy sparkling clean dishes with minimal fuss. There's no need to prewash, just press the dedicated Push&Go button to start a daily 85-minute cycle. It's so easy, the whole family can get involved.



Fast&Clean

Perfectly clean dishes in just 28 minutes

Enjoy perfectly clean dishes in less than half an hour with the Fast&Clean cycle. From last minute dinner plates to cups for the kids, spend less time washing dishes and more time with the family.



eXtra Cycle

Designed to make life easier when washing larger items

Say goodbye to handwashing large dishes. The eXtra cycle perfectly washes all the largest kitchen items, such as pots and pans, oven trays and pizza tins, in just one hour.



eXtra Hygiene

Maximum hygiene with zero worry

Maximise the cleanliness and hygiene of all your dishes. The hot rinse cycle washes at 72°C for 100 minutes, eliminating 99.9999%* of bacteria for a worry-free hygienic clean.

*For total sterilisation we recommend an additional clean using a sterile solution



Adjustable Basket

Flexible and convenient for the largest of family meals

The height-adjustable top basket makes dishwashing easy when loading and unloading larger items. It can be easily moved or removed to maximise loading capacity and is perfect for the largest family meals.





Freestanding Dishwashers

Say goodbye to arguments over the washing up

With full-sized and slimline models available, there's an option to suit your family's needs, making cleaning up after family meals a breeze.



Fast&Clean

Perfectly clean dishes in just 28 minutes

Enjoy perfectly clean dishes in less than half an hour with the Fast&Clean cycle. From last minute dinner plates to cups for the kids, spend less time washing dishes and more time with the family.



Push&Go

Clean and dry dishes with just one push

Enjoy sparkling clean dishes with minimal fuss. There's no need to prewash, just press the dedicated Push&Go button to start a daily 85-minute cycle. It's so easy, the whole family can get involved.



Adjustable Basket

Flexible and convenient for the largest of family meals

The height-adjustable top basket makes dishwashing easy when loading and unloading larger items. It can be easily moved or removed to maximise loading capacity and is perfect for the largest family meals.



Slimline

When you're limited on kitchen space our slimline dishwashers fit into a 45cm space

Ditch the delegation of the washing and drying up after dinner and choose a reliable and energy efficient dishwasher.



Built-In Laundry

Get the laundry completed that little bit faster

Our range of built-in washing machines and washer dryers help get the laundry completed that little bit faster, with minimal effort. With Push&Go technology everyone in the family can get involved.



Push&Go

Just one push for clean laundry in only 45 minutes

Press and hold the blue button for two seconds and the machine will automatically start a daily, 30°C cycle. It's so easy the whole family can do their part and share the chores.



Wash&Dry 45"

Cupboard ready laundry in just 45 minutes

For when you need clothes in a hurry, from a work outfit to your kid's uniform, the Wash&Dry 45" cycle ensures 1kg of clean and dry laundry in just 45 minutes.



Water Balance+

Save energy, water and time

Save energy, water and time with a clever sensor that optimises water consumption during all washing stages. Only the essential quantity of water is used, so you never waste a single drop.



Rapid 30"

Laundry done in just half an hour

Perfect for busy schedules or last-minute rushes, wash half a load in just half an hour at an energy-efficient temperature of 30°C.



Wool Care

The easy way to look after your family's woollens

Keep your woollens feeling soft and new. The Wool Care cycle is safe to use on clothes and blankets that feature the hand wash only symbol.





Freestanding Laundry

When there's a pile of laundry to contend with, Indesit has you covered.

Our range of freestanding washing machines and washer dryers make keeping on top of the family's laundry a breeze, while being energy efficient, so you can keep an eye on your energy bills.



Full Load **Fast Cycles**

Three full-load Fast Cycles in less than an hour

Indesit offers the only washing machine with three full load Fast Cycles that take less than an hour. The cycles include the Mixed 40°C and Cotton 60°C, which take 59 minutes, as well as a Cotton 40°C option at just 45 minutes.



Push&Go

Just one push for clean laundry in only 45 minutes

Press and hold the blue button for two seconds and the machine will automatically start a daily, 30°C cycle. It's so easy the whole family can do their part and share the chores.



Easy Iron

Spend less time ironing

Make ironing easier than ever with the Easy Iron option. This function saves you valuable time on household chores by reducing creases on your laundry, making ironing a breeze.



Water Balance+

Save up to 50% of water*

Our Water Balance+ sensor makes sure your washing machine only uses the necessary amount of water, so you never waste a drop, conserving resources with every wash.

*Tested on Cotton Coloured cycle + full load vs half load.



Refrigeration

Keeping your food fresh, efficiently

Enjoy excellent cooling performance for your fresh and frozen foods, alongside flexible storage options. Designed to make storing those big weekly shops easier for every family.




Push&Go Faster temperature recovery with Push&Go

Returned home from the big weekly shop? The Push&Go button activates extra cooling power for a faster temperature recovery in your fridge, keeping your food fresh.



Total No Frost No more defrosting your fridge or freezer

Save on food waste and never defrost your fridge or freezer again. Total No Frost eliminates ice and moisture build-up, so fresh food lasts longer, and there's no need to waste time defrosting your appliance.



FreshSpace+ Freshness for your fruit and vegetables

The FreshSpace+ drawer has a handy humidity slider, so you can set the right conditions and keep your fruit and veggies fresh.



Water Balance+ Save up to 50% of water*

Our Water Balance+ sensor makes sure your washing machine only uses the necessary amount of water, so you never waste a drop, conserving resources with every wash.

*Tested on Cotton Coloured cycle + full load vs half load.



Indesit, Morley Way,
Peterborough, PE2 9JB, UK

03448 11 10 09 from the UK